

Windows Vista 64-bit Driver Version 173.047 for V.92 PCI Modem

Installation Instructions

1. Remove any previously installed version of the V.92 PCI modem driver:
 - a** From the **Start menu**, select **Control Panel** → **Programs** → **Programs and Features**.
 - b** Select **V.92 PCI Voice Faxmodem** (this device name may vary slightly) and then click **Uninstall**.
 - c** When the uninstallation is complete, click **Finish**.
 - d** If the **Phone and Modem Options** control panel appears, select the **V.92 PCI Voice Faxmodem** and then click **Remove**. Otherwise, click **Cancel**.
2. If you have not done so, shut down your computer and then physically install the PCI modem card. Refer to the modem's Quick Start or User Guide if necessary.
3. Turn your computer back on.
4. If a **Found New Hardware** dialog box appears, select **Don't show this message again for this device**. (Note: If this window is minimized, click the Found New Hardware button in the taskbar to restore it.)

If a **User Account Control** message box appears saying that Windows needs your permission to continue, click **Continue**.
5. Open the **Vista64** folder, which is inside the **V92PCI_Setup64_173047** folder, and then double-click the **Setup64** application icon.

If a **User Account Control** message box appears saying that an unidentified program wants access to your computer, click **Allow**.
6. After the Device Driver Installation Wizard initializes, click **OK** to continue the installation.

If a **Windows Security** message box appears saying that Windows can't verify the publisher of this driver software, select **Install this driver software anyway**.
7. When the installation is complete, click **OK**.
8. To confirm a successful installation:
 - a** From the **Start menu**, select **Control Panel** → **Hardware and Sound** → **Phone and Modem Options**.
 - b** If prompted, enter your **Location Information** and then click the **Modems** tab.
 - c** Select **V.92 PCI Voice Faxmodem**, click the **Properties** button, and then click the **Diagnostics** tab.
 - d** Click the **Query Modem** button.
 - e** In the list of Commands and Responses, scroll down to AT13 and check that the response is **173.047.000.000**.

Congratulations! You have successfully installed your V.92 PCI Modem.